

UNITED STATES MARINE CORPS
Logistics Operations School
Marine Corps Combat Service Support Schools
Training Command
PSC Box 20041
Camp Lejeune, North Carolina 28542-0041

STUDENT HANDOUT

STE/ICE-R TEST PROCEDURES

This handout will be helpful as a reference when using the STE/ICE-R. The handout contains information such as possible errors, test procedure, control codes, and additional notes as necessary. The following chart will help you find the test you need. The STE/ICE setup and internal checks (test no. G01, Page VII-31) must be performed prior to performing tests. A complete description and operation of the STE/ICE-R is found on page VII-21. See TM 9-4910-571-12&P for additional information.

TEST NAME	TEST #	PAGE #
ENGINE RPM (AVERAGE)	10	VII-2
POWER TEST (RPM/SEC)	12	VII-3
POWER TEST (PERCENT)	13	VII-4
COMPRESSION UNBALANCE TEST	14	VII-5
FUEL SUPPLY PRESSURE (PSI)	24	VII-6
PRESSURE (PSI) 0 TO 1000	50	VII-7
BATTERY VOLTAGE	67	VII-8
STARTER MOTOR VOLTAGE	68	VII-9
STARTER NEGATIVE CABLE VOLTAGE DROP	69	VII-10
STARTER SOLENOID VOLTS	70	VII-11
STARTER CURRENT AVERAGE	71	VII-12
CURRENT FIRST PEAK	72	VII-13
BATTERY INTERNAL RESISTANCE	73	VII-14
STARTER CIRCUIT RESISTANCE	74	VII-15
BATTERY RESISTANCE CHANGE	75	VII-16
BATTERY CURRENT	80	VII-17
DC VOLTAGE 0 TO 45 VOLTS	89	VII-18
DC CURRENT 0 TO 1500 AMPS	90	VII-19
RESISTANCE AND CONTINUITY 0 TO 4500 OHMS	91	VII-20

STE/ICE-R TEST PROCEDURES - AOMC 6313

This handout will be helpful as a reference when using the STE/ICE-R. The handout contains information such as possible errors, test procedure, control codes, and

additional notes as necessary. The following chart will help you find the test you need. The STE/ICE setup and internal checks (test no. G01, Page VII-31) must be performed prior to performing tests. A complete description and operation of the STE/ICE-R is found on page VII-21. See TM 9-4910-571-12&P for additional information.

TEST NAME	TEST #	PAGE #
ENGINE RPM (AVERAGE)	10	VII-2
POWER TEST (RPM/SEC)	12	VII-3
POWER TEST (PERCENT)	13	VII-4
COMPRESSION UNBALANCE TEST	14	VII-5
FUEL SUPPLY PRESSURE (PSI)	24	VII-6
PRESSURE (PSI) 0 TO 1000	50	VII-7
BATTERY VOLTAGE	67	VII-8
STARTER MOTOR VOLTAGE	68	VII-9
STARTER NEGATIVE CABLE VOLTAGE DROP	69	VII-10
STARTER SOLENOID VOLTS	70	VII-11
STARTER CURRENT AVERAGE	71	VII-12
CURRENT FIRST PEAK	72	VII-13
BATTERY INTERNAL RESISTANCE	73	VII-14
STARTER CIRCUIT RESISTANCE	74	VII-15
BATTERY RESISTANCE CHANGE	75	VII-16
BATTERY CURRENT	80	VII-17
DC VOLTAGE 0 TO 45 VOLTS	89	VII-18
DC CURRENT 0 TO 1500 AMPS	90	VII-19
RESISTANCE AND CONTINUITY 0 TO 4500 OHMS	91	VII-20